GENERAL INFORMATION





TM-630A

TM-616

This 24-Hour/7-Day Time Switch series are with high load output current 30A. The time switch can be operated in 4 separate power supplies, ranges from 240 Vacto 12 Vdc. such as lighting control, HVACR, pumps, motors, fan controls, access controls, OEM applications, agricultural facilities, and general purpose electrical circuits.

This Digital Timer is accurate to the minute, designed with 17 ON/OFF (event) per day. Rechargeable battery is for retaining the current time and the program setting during Timer's operating power disconnected.

Also, it provides 15-combination of Daily-Programs which can leads great convenience to users upon choosing desired DAYS of WEEK

TECHNICAL DATA

Power supply: AC 220V/240V/110V,50/60Hz

DC 12V/24V/48V

Hysteresis: 2 sec/day (25℃) ON/OFF operation: 17 ON/OFF Power consuption: 2VA(MAX) Output control: 30A 250VAC


Service life: Mechancal 107, Electrical 107


Minimum interval: 1 minute

Power reserve: 3 years (Lithium battery

Ambient temperature: -25~+60 Ambient humidity: 35~85%RH ℃ Dimensions: 98*55*40mm TM-630A 120*74*52mm TM-616

WIRING DIAGRAM





PROGRAMMING THE TIMER

A. Functional description to buttons on panel

1. P: Programs review & setting programs

2.MANUAL: To select "ON.AUTO or OFF" 3. : To adjust current DAY and TIME

4.D+: To adjust day of week

5. H+: To adjust Hour 6.M+: To adjust minute

7. RESET: Reset Timer's setting 8. LED: To indicate ON/OFF status

Press **RESET** button to reset Timer berfore programming

B.Adjusting CLOCK

Press and hold \oplus and then press **D+** key, **H+** key, **M+** key respectively to adjust clock of Timer to accurate DATE. HOUR, MINUTE, LCD screen shall indicate 0:00~23:59

C.Start to programming the TIMER


1. Press (P) key. LCD screen shall show | 1 --:---



- 2. Press D+ key to select any of 15-combination of Daily-Programs to your application demand. Continuing to press Dakey, LCD shall alternating indicate among 15-combinations.
- M+ respectively to set 3. Press **H+**, desired Hour and Minute for of
- 4. After finished setting of on 1, Press P key again,
- 5. Press D+ key to select any of 15-combination of Daily-Programs to your application demand Continuing to press D+ key, LCD shall alternating indicate among 15-combinations.

Day-combination chosen in each of ON/OFF program-period must be consistent

- 6. Repeat Programming procedure "3" to set desired Hour & Minute for 10FF
- 7.When finished setting on & 1 the Press P shall appear on LCD screen.
- 8. Repeat programming procedure above to complete rest of ON/OFF program-period(event)



9. When finished program-setting(event), press (), Timer shall start to execute programs.

D.To review programs

Keep to press P , display on LCD screen shall alternating display among each of 17 ON/OFF

CAUTION

Remark:

- 1. The connection and installation of electrical devices may only be carried out by a qualified electrician.
- 2. For voltage and electrical RATING information, please refer to the markings on the back of timer.
- 3. See the back of timer for proper wire connections.
- 4. Timer may need to be connected to power source in order to set the program.
- 5. Press RESET key before first use to clear memory.
- 6.Do not immerse timer in water or any other liquid.